



IN SERVICE INSPECTION

Soft Body Armour (SBA) and Ballistic Blanket products should be inspected periodically for damage or wear. For SBA this is recommended each time that the carrier is removed for washing. Whereas for ballistic blankets inspection intervals may be set by the user however if they are being disassembled, unpacked/stored or moved to an alternate area these are optimum inspection points.

Key inspection points;

- Verify there are no rips, wear or tears in the fabric
- Verify all webbing straps and attachments points are secure
- Remove any thread or lint from the surface.
- Ensure there are no areas where the ballistic panel is exposed.
- Verify the ballistic material is not bunched up or folded.

Damage to the cover or if the ballistic material is visible requires replacement of the panel.

Proper inspection as well as use and care of your SBA / Ballistic Blanket is essential in maintaining it's viability throughout the warranted period of the product.